



Back Wall
Back Wall

Set 46	41'0"
Set 45	40'0"
Set 44	39'0"
Set 43	38'0"
Set 41	Blackout Drop
Set 40	37'0"
Set 39	36'0"
Set 38	35'0"
Set 37	34'0"
Set 36	33'0"
Set 35	32'0"
Set 34	# 7 Elec. Sky Cycle
Set 33	Opera Drop
Set 32	Black Scrim
Set 31	30'0"
Set 30	28'0"

Orchestra shell on truss and chain holes here
-does not strike-

Set 29	#6 Electric
Set 28	#4 Legs
Set 27	#4 Border
Set 26	Blackout Drop
Set 24	20'0"
Set 23	#2 Ceiling - Does Not Mew
Set 22	#5 Electric
Set 21	Projection Screen 10' x 14.5'
Set 20	#3 Legs
Set 19	#3 Border
Set 18	18'0"
Set 17	#4 Electric
Set 16	#3 Electric
Set 15	15'0"
Set 14	12'0"
Set 13	11'0"
Set 12	10'0"
Set 11	#2 Electric
Set 10	#1 Ceiling - Does Not Mew
Set 9	#2 Legs
Set 8	#2 Border
Set 7	7'5"
Set 6	6'5"
Set 5	#1 Electric
Set 4	3'5"
Set 3	2'5"
Set 2	2'5"
Set 1	2'5"

KEY

	Stand 12' Fresnel 2K
	ALTMAN 6x9 1000w
	ALTMAN 6x12 1000w
	ALTMAN 6x16 1000w
	ALTMAN 6x22 1000w

NOTES
-Units are hung on 18" centers unless noted.
-Typ. indicates that the next several
instruments are the same measurement.
-Always confirm the lowest function for any